



Mudflaps rear AUDI Q7, 2015->

Preparation


2x  - original screw

1x  - metal bracket

 ! The bracket is installed
on the standard fender guard




Installation

2x  - original screw

1x  - screw $\varnothing 4,2 \times 16$ mm

1x  - screw $\varnothing 6 \times 15$ mm

1x  - spring washer



Art.: EXP.NLF.04.01.E13

Set package

Mudflap - 2 pcs.

Screw $\varnothing 4,2 \times 16$ mm - 2 pcs. (TL-028)

Screw $\varnothing 6 \times 15$ mm - 2 pcs. (TL-021)

Spring washer - 2 pcs. (TL-048)

Metal bracket - 2 pcs. (TL-026)